



## **EMERGO Metal Treatment – General guidelines and instructions for use**

1. General guidelines for safe use of Innogel B450
  - I. Use the product according to the directions on the label and the user instruction.
  - II. Apply the product only on surfaces for which the product is intended, stainless steel and other metals.
  - III. Keep Products always out of reach for children.
  - IV. Do not swallow the products. In case of swallowing immediately consult a doctor and show packaging or label.
  - V. Avoid contact with the eyes and skin. In case of contact of the product with the eye rinse immediately with excessive amount of water and obtain expert medical advice.
  - VI. In order to avoid possible undesirable irritations it is recommended to wear (watertight) gloves during cleaning.
  - VII. Don't use the products in strong sunlight.
  
2. User instruction Innogel B450
  - I. Innogel B450 needs to be applied undiluted with a damp sponge or brush. Let the product subsequently be absorbed 4 – 24 hours.
  - II. Remove the residues to rinse abundantly with. Notice that the loss of oxides can damage the surface. This happens particularly in case the surface is polished.
  - III. Use by preference the base cleaner Innoprotect B580 that, in addition to neutralization, also leaves a nano layer behind in order to prevent new corrosion as much as possible.
  - IV. Innogel B450 must keep frost-free.
  - V. When using 5 kg buckets, Emergo Metal Treatment recommends to make smaller portions before using the product. This will prevent that a used brush can cause contaminations of the product.
  - VI. If the surface is not clean after this treatment, it can be repeated.