

EMERGO Metal Treatment – General guidelines and instructions for use

1. General guidelines for safe use of EMERGO Metal Treatment products

- I. Use the product according to the directions on the label and the user instruction.
- II. Apply the product only on surfaces for which the product is intended, stainless steel and other metals.
- III. Keep Products always out of reach for children.
- IV. Do not swallow the products. In case of swallowing immediately consult a doctor and show packaging or label.
- V. Avoid contact with the eyes and skin. In case of contact of the product with the eye rinse immediately with excessive amount of water and obtain expert medical advice.
- VI. In order to avoid possible undesirable irritations we recommended wearing (watertight) gloves during cleaning.
- VII. Do not use the products in strong sunlight.

2. User instruction Innosoft B570 ®

- I. After intensive shaking of the Innosoft B570 packaging the cleaner needs to be applied undiluted with a damp sponge or pad. Let the product subsequently be absorbed briefly (around 1 minute) and start after that to move the sponge or pad with some pressure over the material (rubbing/polishing).
- II. The special sponge or pad needs to be moved in the rolling direction of the material or in the direction of the brushed or polished surface. If the oxidation is hard to remove one can also use the white (scrubbing) side of the sponge.
- III. One has to consider that the removed oxides may damage a surface slightly. That will be especially become apparent when the surface has been polished.
- IV. Remove the residues carefully with water or a damp cloth. The latter should be done while applying light pressure in order to prevent that dirt is rubbed into the pores again.
- V. Use by preference the base cleaner Innoprotect B580 that, in addition to neutralization, also leaves a nano layer behind in order to prevent new corrosion as much as possible.
- VI. Do not let Innosoft B570 ® get in contact with natural stone.

3. User instruction Innoprotect B580 ®

- I. Dilute with water for daily use 50ml on 1 liter of water.
- II. In case of use as after treatment or on a surface treated with Innosoft B570 use a 1 in 4 dilution.
- III. Apply Innoprotect B580 with a sponge or cloth.
- IV. For a dry result rinse afterwards.
- V. Always use cold water.

4. User instruction Innospray B600 ®

- I. For an optimal dry result, the Innospray B600 should be applied on a micro fiber cloth and then wipe off the surface evenly. Do not apply the Innospray B600 directly on the surface.
- II. Use Innospray B600 pure, it is a ready-to-use cleaner.
- III. Use Innospray B600 only on waterproof surfaces.
- IV. Do not use Innospray B600 on piano varnish and acrylic glass.

5. User instruction Innopolish B520 ®

- I. Use Innopolish B520 for the cleaning of polluted and dull surfaces.
- II. Apply Innopolish B520 on a damp cloth or sponge. Clean the surface and possibly rub afterwards with a dry cloth.
- III. Rub when desirable with a soft afterwards to create gloss.
- IV. Suitable for stainless steel, nickel, copper, bronze, chrome and aluminum.

